



TO REMOVE OLD INK CARTRIDGE

Step # 1

Push Cable Forward into tapered pen barrel section .This action will cause end of ink cartridge to protrude out 1/2".

Step # 2

Hold end of ink cartridge after it has protruded to stop it from returning back to pen barrel.

IMPORTANT- Do not allow ink cartridge to spring back into pen barrel section

Step # 3

Holding onto end of ink cartridges AND front Pen Barrel section ,pull off tapered Pen Barrel Section.

Step # 4

The ink cartridge is now exposed and can be removed from front Pen Barrel Section.

TO INSERT NEW INK CARTRIDGE

Step # 1

Insert new ink cartridge into front Pen Barrel Section

Step # 2

Now push ink cartridge barrel further with paper clip until the end of ink cartridge protrudes 1/2" out of end of barrel.

Step # 3

Hold end of ink cartridge after it has protruded to stop it from returning back into pen barrel.

Step # 4

Push tapered pen barrel section over ink cartridge barrel onto end of front pen barrel. Pen is now reassembled .

SECURITY PEN SET PS2592-81

INK REFILL MODEL PS259-00

matel

13205 Estrella Avenue, Bldg # A
Gardena, CA 90248

Phone: 800 217 7606, 310 217 9111

Fax: 310 538 8949

WEBSITE : www.matelinc.com